



Contents

Aluminium Doors	4
Arendal	5
Boras	6
Eslov	8
Hamar	9
Kalle	10
Laguna & Lesini	1
Lovel	1:
Lucid	1
Rauma	1
Salo	1
Shaker no Grooves	1
Siljan	2
Tonsberg	2
Tornio	2
Bedroom Accessories	2
Lighting	2
Cabinets & Upgrades	2
Cabinet Colour Options	2
Melamine Door & Colour Ranges	2
Emporio Skins Door & Colour Ranges	3
Vinyl Door & Colour Ranges	3
Legno Vinyl Door & Colour Ranges	3
Aluminium Door Ranges	4
Handles	4
Door Care and Maintenance	5



Aluminium Doors

Elevate your bedroom with the sophistication of our aluminium doors. Choose from two stunning glass options: smoked mirror for a touch of glamour or smoked tinted glass for a hint of mystery. Combine these doors with strategically placed lighting to create a truly elegant and moody atmosphere, perfect for relaxation.



4 | ALKU BROCHURE 2024 HANDLE: INT89



Arendal

Simple yet elegant, this flat panel door with a large radius edge creates a soft and inviting look.









Eslov

Exuding soft elegance, the Eslov door showcases a wide shaker frame and a beaded detail gracing the center panel.



Hamar

Embrace a modern farmhouse aesthetic with the Hamar door. This contemporary take on Shaker design features a slim frame, creating a clean and airy feel in your bedroom. The tall doors boast a distinctive cross rail, adding a touch of visual interest.







Laguna & Lesini

Contemporary and elegant mix of our Laguna matte finish coupled with Lesini Elements range or add simplicity and choose just one of the many decors available.





Lovel

This simple but elegant ultra matte finish door is smooth to the touch and offers many colour combinations. Offered to maximise the space in any room.





Lucid

Representing pure luxury with its deep reflective surface this glass-like sister to the Lovel bedroom makes for a bright and luminous room.









Salo

With its unique reeded effect grooves, the Salo door creates a captivating play of light and shadow, adding a touch of modern intrigue.









Shaker no Grooves

A perennial favorite, the Shaker door defines timeless design. Its clean lines and wide rails create an enduring elegance that complements any bedroom style.









Tonsberg

The perfect complement to a loft dwelling, the Tonsberg slab door features a unique handle detail. When mixed with full glazed black aluminum doors, it creates a truly uber-modern feel.





Tornio


Offering timeless sophistication, the Tornio boasts classic panels, a double outer step, and a raised center panel.



Accessories



Pull down rail





Pull out shoe rack



Pullout and swivel mirror



Pullout mirror





Tie and Belt Rack



Wire Drawer





Trouser hanger 24 | ALKU BROCHURE 2024



Jewellery Drawer




Metallic Drawer

Lighting



Internal Cabinet Lighting



Glass Wall Unit Lights




Under Wall Cabinet Lighting



Glass Wall Unit Lights

Our Cabinets... built to last!





• Hettich AvanTech drawer box is only available in White.



• **Glass side panel** with Hettich drawers are available as an upgrade.



• **Glass front panel** with Hettich drawers are available as an upgrade.

Cabinet Colour Options










Laguna Colour Options












Lesini Colour Options







Concrete























Slab lacquered laminate ultra matte with matching 1mm edge.



Lovel Colour Options



















Light Grey Chicago White Concrete






Style

Slab lacquered laminate ultra gloss with matching 1mm edge.



Lucid Colour Options











ere Dust Grey Indigo Blue Ligh



Emporio Skins Door & Colour Ranges

EMPORIO SKINS

Style Slab MFC heavy embossed texture 1mm matched edge.



Emporio Skin Options



ARENDAL

Flat panel door with a large radius edge



BORAS

One panel door with small outer radius 65mm rails, recessed centre panel and cockbead.



BORAS THREE PANEL CIRCLE FRETTED

Style

Three panel door with small outer radius 65mm rails, recessed centre panel and cockbead. Circle fretted glass doors.

Please note three panels are equal size and scaled to match door height.







BORAS FOUR PANEL CROSS FRETTED

Style


Four panel door with small outer radius 65mm rails, recessed centre panel and cockbead. Cross fretted glass doors.


Please note four panels are equal size and scaled to match door height.

ESLOV

Style

Four panel shaker style with beaded inner detail. 95mm rail.





KALLE

Style

Two panel shaker style door with 80mm rail and cockbead

KIRUNA

Four panel door with radius outer, 65mm rails and chamfered centre rebated panel detail.

Please note four panels are equal size and scaled to match door height.




RAUMA

Single panel door with rebate for handle, cockbead with chamfered centre panel. 65mm rail.

Please note max hole centre to be used on this door 192mm and below. Handle block will be positioned in the centre of the door as standard, please specify a height if required.



Horizontal groove reeded door. 36mm Stiles.



SHAKER INFRAME

Style Faux Shaker In-Frame. 120mm rails.

SHAKER NO GROOVES

Style S

Shaker style with 95mm rails.



SILJAN

Style

Radius round with a step outer, 70mm rails and chamfered inner route with raised centre panel.




36 | ALKU BROCHURE 2024

Vinyl Door & Colour Ranges


TONSBERG

22mm thick slab doors with small radius and rebate handle.



TORNIO

Radius round with a double step outer, 70mm rails and chamfered inner route with raised centre





Vinyl Door & Colour Ranges


Matte



Gloss



Oak Grained





Oak Grained

Grained



Woodgrains




Legno Vinyl Door & Colour Ranges

HAMAR

5 Piece Shaker Style Door with embossed vinyl 60mm Stiles, 22mm thick




Hamar Colour Options








Aluminium Door Ranges



SMOKED MIRROR ALUMINIUM DOOR

45mm Matte Black profile frame Aluminium with Smoked Mirror Glass



SMOKED TINTED ALUMINIUM DOOR

45mm Matte Black Aluminium profile frame with Aluminium with Smoked Tinted Glass

Handles

Choose from our extensive range of handles and knobs to complement your new Alku Bedroom

Brushed



UH197 Brushed Satin Nickel



UH200 Brushed Satin Nickel



UH304 Brushed Satin Brass



UH305 Brushed Satin Brass



UH204 Silk Polished



UH203 Brushed Brass



UH215 Inox Look



UH219 Inox Look



UH146 Brushed Steel



UH179 Brushed Nickel



UH171 Brushed Nickel



UH174 Brushed Nickel



UH184 Brushed Nickel



UH148 Brushed Steel



UH201 Brushed Copper



UH317 Brushed Nickel



UH86 Brushed Chrome



UH178 Brushed Nickel



FH814 **Brushed Brass**



FH817 Brushed Brass



FH815 Inox Look



FH818 Inox Look



FH816 Brushed Matte Black



FH819 Brushed Matte Black



UH52 to UH53 (various lengths available) Brushed Nickel



FH820 Brushed Brass



FH821 Inox Look



FH822 Brushed Anthracite



FH824 Inox Look



FH825 Brushed Antracite



FH828 Inox Look



FH831 Inox Look



FH833 Inox Look



FH834 Brushed Antracite



FH836 **Brushed Brass**



FH837 Inox Look



FH841 Inox Look



UH350 Inox Look



UH303 Brushed Satin Brass



UH302 Brushed Satin Brass



UH301 Brushed Satin Brass



UH269 Brushed Nickel



UH267 Brushed Satin Brass



FH843 Brushed Brass



FH847 Brushed Brass



FH844 Inox Look



FH848 Inox Look



FH845 Brushed Matte Black



FH849 Brushed Matte Black



FH846 Brushed Anthracite



FH850 Brushed Anthracite



UH342, UH343 & UH344 Inox Look



UH339, UH340 & UH341 Brushed Brass



UH345, UH346 & UH347 Brushed Matte Black



UH266 Brushed Nickel



UH263 Brushed Nickel



UH370 & UH371 **Brushed Nickel**



UH369 **Brushed Nickel**



UH364 & UH365 Antique Brushed Brass



UH363 **Antique Brushed Brass**



UH377 **Brushed Nickel**



UH376 **Brushed Nickel**



UH373 **Antique Brushed Brass**



UH372 **Antique Brushed Brass**



UH308 **Brushed Satin Nickel**



UH307 Brushed Satin Nickel



UH306 Brushed Satin Nickel



UH272 **Brushed Nickel**



UH393 & UH394 **Brushed Nickel**



UH389 & UH390 **Brushed Brass**



UH385 **Brushed Nickel**



UH384 **Brushed Nickel**



UH381 **Brushed Brass**



UH380 **Brushed Brass**



UH388 **Brushed Nickel**



UH386 **Brushed Brass**



UH336 Inox Look



UH335 Inox Look



UH334 Brushed Brass



UH333 Brushed Brass



UH338 Brushed Matte Black



UN337 Brushed Matte Black



UH277 Brushed Brass



UH273 Brushed Brass



UH278 Inox Look



UH274 Inox Look



UH279 Brushed Anthracite



UH275 Brushed Anthracite



UH280 Brushed Matte Black



UH276 Brushed Matte Black



UH313 Brushed Satin Brass



UH321 & UH322 Brushed Nickel



UH323 Brushed Nickel



UH324 Brushed Nickel



UH326 Brushed Nickel



UH209 Inox Look



INT87 **Brushed Copper**



INT90 **Brushed Brass**



INT15 Brushed Nickel



INT155 **Brushed Nickel**



INT86 **Brushed Copper**



INT88 **Brushed Copper**



INT91 **Brushed Brass**



INT89 **Brushed Brass**



INT81 **Brushed Copper**



INT105 Brushed Nickle



INT106 **Brushed Nickle**



INT109 **Brushed Brass**



INT110 **Brushed Brass**



INT19, INT20 & INT21 **Brushed Nickel**



INT421 **Brushed Brass**



INT422 & INT423 **Brushed Brass**



INT424 **Brushed Brass**



INT425 **Brushed Brass**



INT426 **Brushed Brass**



INT427 **Brushed Brass**

Polished



UH191 Polished Chrome



UH193 Polished Chrome



UH192 Polished Brass



UH194 Polished Brass



UH195 Polished Nickel



UH198 Polished Nickel



UH202 Mirror Polished Chrome



UH205 Polished Brass



UH169 Chrome



UH166 Chrome



UH241 & UH244 (various lengths available) Chrome



UH227 & UH230 (various lengths available) Chrome



UH172 Chrome



UH175 Chrome



UH180 Chrome



UH187 Chrome



UH165 Chrome



UH145 Chrome



UH153 Polished Nickel



UH156 Polished Nickel



UH159 Polished Nickel



UH147 Chrome



UH164 Chrome



UH177 Chrome



UH187 Chrome



UH315 Chrome



UH311 Chrome



UH316 Chrome



UH314 Chrome



UH310 Chrome



UH309 Chrome



UH357 Bright Nickel



UH358 Bright Nickel



UH325 Chrome



UH312 Chrome



UH379 Chrome



UH378 Chrome



UH255 Satin Nickel



UH256 Black Nickel



UH259 Satin Nickel



UH260 Black Nickel



UH257 Satin Nickel



UH258 Black Nickel



UH207 Chrome



INT315 Polished Chrome



INT56 Stainless Steel



INT31 Chrome



INT316 Polished Chrome



INT317 Polished Chrome



INT118 Chrome



INT11 & INT115 Crystal & Polished Chrome



INT44 Stainless Steel



INT28 & INT285 Chrome



INT29 Chrome



INT96 & INT97 Knurled Steel



INT117 Chrome

Rustic



UH196 American Copper



UH199 American Copper



UH152 American Copper



UH155 American Copper



UH158 American Copper



UH214 Antique Brown



UH218 Antique Brown



UH221 Brass



UH223 Brass



UH226 Brass



UH225 Copper



UH268 Antique Copper



UH173 Pewter



UH176 Pewter



UH319 Brass



UH320 Brass



UH170 Pewter



UH60 Antique Pewter



UH61 Brass



UH154 Pewter



UH157 Pewter



UH160 Pewter



UH99 Pewter



UH104 Pewter



FH839 Antique Grey



FH840 Antique Brown



UH348 Antique Grey



UH349 Antique Brown



FH851 & FH853 Antique Brass



FH855 & FH857 Antique Brass



FH859 Antique Brass



FH861 Antique Brass



UH265 Antique Copper



UH262 Antique Copper



UH264 Satin Brass



UH261 Satin Brass



UH270 Satin Brass



UH271 Antique Copper



UH318 Satin Brass



UH359 Antique Brass



UH360 Antique Brass



UH208 Antique Brown



FH827 Antique Brass



FH830 Antique Brass



INT58 Matte Nickel



INT68 Matte Nickel



INT12 Matte Nickel



INT112 & INT113 Knurled Brass



INT116 Nickel



INT401 Antique Bronze



INT402 & INT403 Antique Bronze



INT404 Antique Bronze



INT405 Antique Bronze



INT406 Antique Bronze



INT407 Antique Bronze



INT430 & INT431 Antique Bronze

Anthracite & Black



UH206 Matte Black



UH216 Matte Black



UH220 Matte Black



UH234 & UH237 (various lengths available) Matte Black Anodized



UH248 & UH251 (various lengths available) Matte Black Anodized



FH823 Matte Black



FH829 Matte Black



FH832 Matte Black



FH826 Matte Black



FH835 Matte Black



FH838 Matte Black



FH842 Matte Black



FH852 & FH854 Matte Black



FH856 & FH858 Matte Black



FH860 Matte Black



FH862 Matte Black



UH361 Matte Black



UH362 Matte Black



UH383 Matte Black



UH382 Matte Black



UH387 Matte Black



UH391 & UH392 Matte Black



UH367 & UH368 Matte Black



UH366 Matte Black



UH375 Matte Black



UH374 Matte Black



UH210 Matte Black



INT99 Matte Black



INT100 Black



INT98 Matte Black



INT102 Black



INT103 Black



INT107 Black



INT108 Black



INT92 & INT93 Knurled Black



INT411 Anthracite



INT412 & INT413 Anthracite



INT414 Anthracite



INT415 Anthracite



INT416 Anthracite



INT417 Anthracite

Timber



UH113 Oak

Lamezia handle



FH801 to FH813 Aluminium, chrome-plated



Cabinet & Door Care and Maintenance

With the appropriate care and maintenance our kitchen doors and components are designed to provide many years of reliable service. To help keep it in the best possible condition please follow the simple guidelines below.

INSTALLATION ADVICE

Pre Installation

Ensure that all new-builds or newly plastered rooms have been left to environmentally stabilise prior to the installation of new kitchen doors. Kitchen doors must not be installed into a damp, or moisture-rich environment as it will cause undesirable movement in the joints and panels of the door. A hygrometer should be used to assess conditions.

To help minimise any potential damage to the kitchen whilst you are installing it, please read and adhere to the following instructions and recommendations:

- We would advise that you make an initial check to confirm that you
 have the correct quantity and sizes of fascias; you can do this by
 referring to the labels attached to the outer packaging.
- The fascias should be stored flat and away from the working area.
 Take extreme care when stacking the fascias with hinges attached to ensure that the hinges do not mark other fascias. Do not lean the fascias against one another, or against any surface without proper protection in-between.
- Ensure that you fully inspect each individual fascia prior to attaching the hinges. Claims for damage to the fascia will not be accepted after the hinges have been attached.
- Take extreme care when unpacking the fascias and do not use sharp blades to cut away the packaging.
- When attaching the hinges, place the fascia face down on a soft clean surface, ensuring that there is no grit, sawdust or other matter underneath that could damage the surface of the fascia whilst the hinges are attached. It is good practice to place a sheet of clean cardboard between the fascia and the flat surface prior to attaching the hinges.
- If the hinges are 'knock-in' type, use a rubber mallet to knock the hinges into the fascia without using excessive force.
- Once the hinges have been attached to a door, hang the door on the
 unit straight away to avoid damage. Do not stack the doors with the
 hinges touching other doors, as this can cause scratches or marks to the
 other fascias
- Do not stack the doors on their ends on any hard surface; this can cause chipping and scratching along the edge of the fascia, especially on the handle edge of ranges with an integral handle. Prior to fitting, the fascias should be stored flat, ensuring that they are not resting on any dirt or debris that may damage or mark the finish.
- You should take extreme care not to put the door down with excessive force on any edge, especially the handle edge, as this will cause crushing/impact damage on these edges.
- Take extreme care not to put the door down on any hard or rough surface such as bare concrete floors, or on any debris such as sawdust, grit or screws, as this can damage the product.
- If the fascias are attached to the carcass, then you should carefully remove the fascias by unclipping the hinges, and storing these flat in a clean safe environment away from your working area, utilising the packing materials from the units.

- Where cutting/scribing décor panels and trim, you must use a sharp
 quality saw blade of the appropriate grade for fine-cutting,
 or a suitable router. Small chips can appear along the cut-edge, and so
 extra care must be taken to minimise the risk of chipping. Using a blunt
 or inappropriate saw blade will produce a poor finish, and this will not
 be covered by the guarantee.
- On Painted Products: Any fine chips along the cut edge should be smoothed with a fine grade sand paper prior to fitting.
- All cut edges should be sealed against moisture ingress using a suitable water resistant sealant/adhesive prior to installation.
- All trims are supplied in long lengths and need to be cut down on site, and again it is important that this is done using the appropriate tools.
- When fitting the plinth, ensure that you check the dimensions of any
 adjacent appliances. On occasion, the plinth may need to be pulled
 forward to ensure that it clears the front of the appliance. This can be
 achieved by fitting blocks using off-cuts to the rear of the plinth prior
 to attaching the plinth clips, to step the plinth forward from its normal
 position.

General Care

As with all kitchen furniture the most common problems found occur as a result of excessive or prolonged exposure to heat and/or moisture. Always ensure that water is not left around sink areas as damage caused as a result is not covered by the guarantee.

Always wipe off excess moisture and be careful with extreme heat sources, such as kettles, ovens and toasters. It is recommended that these heat sources are not placed directly under wall units when they are in use; they generate a higher level of heat and moisture than is often appreciated and can quickly and easily lead to damage of the furniture.

Don't place appliances that create steam (e.g. steamer, coffee maker or kettle) underneath the cabinets so that the steam flows up against the underside of the cabinet and doors.

If using glass cleaner to clean your glass doors be careful not to damage the finish of the door and cabinet parts while cleaning. Do not spray glass cleaner directly on to the glass or cabinet parts as this may discolour the finish of your kitchen cabinets. Instead, spray a small amount of cleaner on to a lint free cloth or paper towel then wipe the glass.

Don't open the door of the dishwasher immediately after the programme has ended, as exposure to heat and the high humidity increases the risk that the door may absorb moisture and swell.

Please note that after a period of time it is quite normal for the colouring of kitchen units to mellow in colour. This is not a manufacturing fault and is as a result of exposure to light. This means that any additional parts subsequently ordered for your kitchen, or supplied as replacements may not be an exact colour match. However any additional parts supplied will also mellow over time to blend with your existing units.

The colour of doors and drawer fronts may appear mismatched in colour. This apparent mismatch is sometimes the effect of differing light conditions within your kitchen, (known as metamerism). To check your doors and fascia you should place them side by side in natural daylight for comparison.

Cleaning advice for all door types including timber, painted & foil

- Do not use wax-furniture polish, abrasive or aggressive cleaners, bleach or other hypochlorite (chlorine) based cleaners, multipurpose cleaners, dilutes, acetone, alcohol, solvent or similar products on the door, as this will damage the surface; additionally wax and polishes leave a residue build up that is difficult to remove.
- Only use a 5% soap, 95% water (liquid soap) solution, wiping with a damp (not wet) cloth, finally drying with a soft clean cloth.
- Ensure all cooking splashes are wiped immediately with a damp cloth; and dust with a soft cloth only.
- Never use any abrasive pads or abrasive cleaners on the furniture. Spills and condensation on the fascias/panels should be cleaned and dried immediately.

Foil & High Gloss Finished Doors

Foil/Lacquer coated products are manufactured from the highest quality materials. Please be careful not to puncture the foil/melamine lacquered surface of your panels. These should be kept dry in order to prevent moisture ingress.

Your gloss doors will come with a protective film over the front. You should remove this only after they are installed as the curing process continues for around 72 hours after the film is removed. This means the doors will be liable to scratching and other marks. You should avoid cleaning the doors for at least a few days to prevent any marks appearing on the surface.

You should clean the doors with a soft damp cloth and a mild detergent. Never use any harsh or abrasive cleaners as this may damage the gloss surface of the door. Normal cleaning and polishing may leave minor scratches on the surface of the door, which is quite natural.

Moisture: Periodically clean the interior and exterior surfaces of the door using a soft, damp cloth. Wipe dry all surfaces after cleaning.

Use only cleaning agents that are intended for the materials used in your kitchen. Avoid any agents that contain ammonia, alcohol, bleach or an abrasive.

If the surface of the product is exposed to any oil based substance (for example olive oil, butter, margarine or cooking oil), the spillage must be wiped away immediately to prevent staining. Grease marks caused by these oil-based products can easily be removed by use of a mild detergent, non-abrasive cleaner if used immediately after spillage has happened.

Abrasive cleaners are not recommended for this type of product. Do not expose the doors or panels to a temperature in excess of 60°C

Light: If the doors are supplied with a protective film on the face they must not be directly exposed to sunlight. Once installation is complete, carefully remove the protective film from the front of the fascia. We also advise that colour change is taken into consideration when replacing or fitting new doors some time after the original kitchen has been installed.



